NYMPH

# USER MANUAL

## Specifications

Materials: Silicone + ABS
Weight: 350g
Battery type: Li-ion
Charging voltage: 100 - 240v
Sound level: <49dB
Usage time: 4 hours
Standby: Up to 90 days
Vibration modes: Seven
Size: 200mm (L) * 35mm (W) * 33.5mm (H)

## Product Description

Thea is an advanced vibrator with an elegant shape and ergonomic design; made of medical grade silicone and ABS core wrapped in the smoothest silicone.

Thea is fully-waterproof and simple to use, with a one button interface that allows full control of the seven unique vibration modes.




1 On / Off / Change vibration mode

2 Charging socket

## Disclaimer

**Any of Nymph's distributors, wholesalers and retailers shall not be negligent in any injury, death or unlawful act caused by use or misuse of Nymph's products. This product is a personal massager, any other use is not recommended and guaranteed. Nymph will not be responsible for any complaints or claims if users of Nymph's products do not read and comply with instructions for use and safety. Should any products manufactured by Nymph be found unsafe or not comply with relevant state, territory, or country standards notifications in writing, please contact us directly before any further action be taken.**

© NYMPH. ALL RIGHTS RESERVED

WEBSITE: WWW.NYMPHSEXSTORE.COM

SUPPORT: CONTACT@NYMPHSEXSTORE.COM

CE RoHS

## Cleaning & Storage

The lifespan of your Thea will be greatly increased with proper maintenance and care.

- Nymph recommends you use a water based lubricant.
- Do not use massage oils or hand creams with this massager.
- Always clean your Thea thoroughly before and after each use.
- Wash with warm water and anti-bacterial soap, rinse with clean hot water, then pat dry with a lint-free cloth or towel.
- Never use cleansers containing alcohol, petrol or acetone.
- Avoid leaving your Thea in direct sunlight, and never expose it to extreme heat.
- Store your Thea in a dust free place and keep it away from toys of other materials.

## Charging

*Note: Before each charge make sure the charging socket is free from water or lubricant residue.*

- Prior to first use, charge your Thea for three hours.
- Locate the charging socket on your Thea (see image), and insert the charging cable through the coverering - expect a little resistance the first time you insert the cable.
- Insert the USB end of the cable into the USB port of a laptop/computer, wall adaptor or power bank.
- The LED power light will pulse when charging; when your Thea is fully charged the LED will stop pulsing and emit a steady glow.

- Do not use your Thea while it is charging.
- Do not charge for more than 24 hours.

## Using your Thea

Thea has been designed to be used in the way your mood takes you. For G-spot massage, insert Thea so she curves naturally up into you, pointing up towards the upper wall of your vagina, where the G-spot area is found. Gently work her until she presses comfortably against your G-spot, and vary your movements, applying the pressure you find the most enjoyable. On / Off / Vibration Modes are all controlled by the power button. When your Thea is in use, the LED will light up to show it is active.

1. Press and hold down the Power button for three seconds to turn on your Thea.
2. Press the Power button to cycle through the seven stimulation modes.
3. To turn off your Thea, again press and hold down the power button for three seconds.

## Tips

Feel free to play with sensation and depth by seeing what Thea can do for you in different positions: squatting, lying on your stomach, lying on your back.

Thea offers exciting prospects for those inclined to the sensual utilization of temperature.

- To warm, hold Thea in your hand or hold against your skin for a few minutes, alternatively place Thea in a glass of warm water until she reaches your desired temperature.
- To cool, place Thea in the fridge until her surface temperature meets your needs.